


FIRE DOORSET RESIDENT GUIDE



Identifying your Fire Doorset

Your Fire Doorset will carry traceability labels. This allows manufacturing and certification traceability of your doorset. Never remove traceability labels. You can get the Certificate and the data sheet relating to your doorset from the Certifire register: www.warringtonfire.com

Do not alter your Fire Doorset

All Fire Doorset parts including: frame, intumescent seals, glazed apertures, smoke seals and ironmongery such as letterplate, locks, hinges and eye viewers have been manufactured and fitted by competent and trained Door-Stop International employees.

If any parts need to be replaced because of damage, they must only be replaced by competent individuals with parts listed in the Certificate and data sheet. Replacement parts can be sourced from Door-Stop International.


Any alterations, including ironmongery will invalidate the certification of this Fire Doorset and may impact upon performance in a fire.

Keep your Fire Doorset closed

Fire doors only work when they are closed. Door closers are supplied with Door-Stop International Fire Doorsets. Door closers must not be removed or disengaged, to ensure that in an emergency, the door will remain closed.

Door closers can be adjusted to ensure the door is easy and safe to operate.

FIRE DOORSET CHECKLIST



This checklist provides guidance about general checks that can be undertaken and is not meant to substitute regular in-depth inspection of all parts of the Fire Doorset by a trained and competent person.



Check the traceability labels on the edge of the doorleaf are not damaged or missing.
Never remove traceability labels.



Check the door closes tightly against the frame seals on all edges.



Look for any signs of damage to the red intumescent seals around the inside of the door frame.



Check all hinges for signs of wear and tear. They should be fixed tightly with no missing or broken screws.



Check key turns smoothly in the lock.



Check the doorcloser is adjusted to close the door at a safe speed and the door latches from any angle.
Never remove or disengage door closers.

Door-Stop International recommend full inspection by a competent person at least every three months.

Contact Door-Stop International for information about replacement parts www.door-stop.co.uk.

Note the fire door traceability label and download the certificate and data sheet from www.warringtonfire.com.

Report any concerns about your Fire Doorset, or other fire doors in your building, to your landlord or building owner immediately.